
# Chapter 7: Microarchitecture


# Single-Cycle Control

# Single-Cycle Control




# Single-Cycle Control: Main Decoder

ор	Instr.	RegWrite	ImmSrc	ALUSrc	MemWrite	ResultSrc	Branch	ALUOp
3	lw							
35	sw							
51	R-type							
99	beq							




#### Review: ALU

ALUControl <sub>2:0</sub>	Function
000	add
001	subtract
010	and
011	or
101	SLT




#### Review: ALU

ALUControl <sub>2:0</sub>	Function
000	add
001	subtract
010	and
011	or
101	SLT




#### Single-Cycle Control: ALU Decoder



# Single-Cycle Control: ALU Decoder

ALUOp	funct3	op <sub>5</sub> , funct7 <sub>5</sub>	Instruction	ALUControl <sub>2:0</sub>	
00	Х	Х	lw, sw	000 (add)	
01	Х	X	beq	001 (subtract)	
10	10 000 00, 01, 10		add	000 (add)	
	000	11	sub	001 (subtract)	
	010	Х	slt	101 (set less than)	
	110	Х	or	011 (or)	
	111	X	and	010 (and)	



# Example: and

ор	Instruct	RegWrite	ImmSrc	ALUSrc	MemWrite	ResultSrc	Branch	ALUOp
51	R-type	1	XX	0	0	0	0	10

